

Arctic-Cat 350/366/425 Winch Mount

Winch Mount

PART # 100795-S



Kit Components:

<u>Qty</u>	<u>Part Description</u>
1.....	Rear Bracket
1.....	Front Bracket
2.....	3/8"-16 X 1" HH BOLT GR5 ZINC
2.....	3/8"-16 NYLOCK NUT GR5 ZINC
2.....	3/8" SAE FLAT WASHER ZINC
2.....	M8 X 1.25 X 25MM HFB GR8.8 ZINC
2.....	5/16"-18 X 3/4" HFB GR5 ZINC
2.....	5/16"-18 HEX NUT GR5 ZINC
2.....	5/16" LOCK WASHER ZINC

INSTALLATION INSTRUCTIONS:

1. Remove the front bumper cover.
2. Place the rear mount bracket into location as shown in the below figure. Bolt the rear of the plate with the supplied 5/16" hardware to the frame tabs as shown in the figure below. Do not tighten at this time.
3. Place the front mount bracket into location in front of the bumper as shown in the below figure. Align the roller fairlead holes and assemble to the bumper using the supplied Metric hardware into the stock threaded holes.
4. Tighten all hardware in Step 2 and 3.
5. Assemble your fairlead through both plates.
6. Install your winch to the mount plate per the installation instructions provided with your winch.
7. Re-assemble front bumper cover removed in Step 1.

