


# ARCTIC CAT ALTERRA 500/600/700 PLOW MOUNT

**Plow Mount      PART #106410**

Kit Components:		
Item #	Qty.	Description
1	1	Plow Mount
2	1	Hardware Kit (HK-001)
2.1	4	5/16"-18 X 1" Hex Flange Bolt
2.2	4	5/16"-18 Hex Flange Nylock Nut
3	1	Hardware Kit (HK-018)
3.1	4	5/16"-18 X 1.25" X 1.75" X .75" UBOLT
3.2	8	5/16"-18 Hex Flange Nylock Nut




**500 / 700  
INSTALLATION**

**SEE PAGE 2.**

**600  
INSTALLATION**

**SEE PAGE 3.**





# 500 / 700 INSTALLATION INSTRUCTIONS

**Note:** Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

1. Locate holes (A) in the frame and mark their location on the skid plate by making a mark in the center of the hole from the top side of the frame. Shown in **Figures 1 and 2**.
2. Remove the the front of the skid plate until the marks are visible, then drill (4x) 1/2" holes through the plastic skid plate.
3. Reinstall the skid plate, then align plow mount (**Item 1**) to the drilled holes.

*Note: The drilled holes should now align with holes in the frame (A).*

4. Insert the (4x) bolts (**Item 2.1**) up through the plow mount, then through holes (A). Install the (4x) flange nuts (**Item 2.2**) on the top side of the frame. See **Exploded View and Figures 2 and 3**.
5. Tighten all hardware evenly.
6. See ATV Plow Tube System instruction manual for tube attachment.



# 600 INSTALLATION INSTRUCTIONS

**Note:** Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

1. Measure 2 5/8" inches back from oval cut out in the bottom of the skid plate and make a mark. Hold plow mount (**Item 1**) up to the bottom of the machine. Align front of plow mount to the 2 5/8" line while also centering it from side to side. Using the plow mount as a template, mark holes (**B**) onto the skid plate. Shown in **Figure 4**.

2. Using a 1/2" drill bit, drill the (4x) marked holes (**B**).

*Note: When drilling, be careful for the brake line located behind the skid plate. See **Figures 5 and 6**.*

3. Install the (4x) U Bolts (**Item 3.1**) around the frame and down through the holes that were just drilled. See **Figure 6**.

4. Install plow mount by aligning the holes on mount to the U bolts coming through the skid plate. Install (8x) flange nuts (**Item 3.2**) onto the U Bolts.

5. Tighten all hardware evenly.

6. See ATV Plow Tube System instruction manual for tube attachment.

