

HONDA / ARGO

Plow Mount

PART #106445

Item #	Qty.	Description
1	1	Plow Mount
2	1	Hardware Kit (HK-111)
2.1	4	5/16"-18 X 1.25 X 2.00 U-Bolt
2.2	4	5/16"-18 Hex Flange Nylock Nut

Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

⚠ CAUTION!!! When installin U-Bolts (2.1) over the frame, be sure there are no electrical wires running along the top side of the frame. If there are, slide U-Bolts under the wires.

1. For **Honda**, Install U-Bolts (2.1) onto frame as shown in **Figure 1**. **NOTE:** when plow mount is installed, it will be pushed as far forward on the middle section of the frame allowed as shown in **Figure 1 & 3**.

For **Argo**, place the front U-Bolts (2.1) directly behind the frame gusset as shown in **Figure 2**. **NOTE:** if there is a skid plate installed, drill holes through the plastic skid to push U-Bolts through.

2. Set plow mount (1) with the notch towards the front of the machine in place over U-Bolts (2.1) and secure using nuts (2.2) as shown in **Figure 3**.
3. Tighten all hardware evenly.

