HONDA RINCON 2" REAR REC

Rear Receiver

•		
Item #	Qty.	Description
1	1	Hitch
2	1	Hardware Kit (HK-009)
2.1	1	M10 x 55mm Hex Bolt
2.2	1	M10 Flat Washer
2.3	1	M10 Hex Nut Nylon Lock

🗩 Notice

Torque bolts to ANSI Specs (or OEM specs if applicable), unless otherwise stated. After the first use and at the start of each season, check torque.

Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

Installation Instructions

- Align the hitch (1) with the holes (A) on the rear of the machine. Once aligned, insert bolts (2.1) as shown in Figure 1.
- 2. Place washers (2.2) and lock nuts (2.3) onto bolts (2.1).
- 3. After all hardware is in place, tighten everything evenly.

PART #100790 Rev B









