

ARCTIC CAT ALTERRA 500 / 700

PLOW MOUNT

Plow Mount

PART # 105825

Hardware Kit: HK-001

Kit Components:

Item #	Qty.	Description
1	1	Plow Mount
2	4	5/16"-18 X 1" Hex Flange Bolt
3	4	5/16"-18 Hex Flange Nylock Nut

INSTALLATION INSTRUCTIONS:

Note: Make sure all of the hardware needed to complete this mount are in the package. Read through and understand the instructions before installing.

1. Mark the area on both sides of the skid plate where the bolts will need to come down through the factory holes in the frame. Shown in [Figure 2](#).
2. Take the front of the skid plate off until you can see your marks and drill (4) 1/2" holes through the plastic skid plate.
3. Mount the skid plate back up then line your plow mount up to the drilled holes. Shown in [Figures 2](#).
4. Insert the (4) bolts up through the holes and attach the flange nut on the top side.
5. Tighten all hardware down.
6. See ATV Plow Tube System instruction manual for tube attachment.

