

# Textron Offroad Alterra 500 Plow Mount

## Plow Mount

## Part # 106085

### Kit Components:

Item #	Qty.	Description
1	1	Plow Mount
2	1	HK-111
2.1	4	5/16"-18 x 1.25 x 2.00 U-Bolt 1.00 Thread
2.2	8	5/16"-18 Hex Flange Nylock Nut

### INSTALLATION INSTRUCTIONS:

**Note:** Make sure all of the hardware needed to complete this mount is in the package. Read through and understand the instructions before installing.

1. Hold plow mount (1) in place and bolt the rear of the mount using two U-Bolts (2.1) and four nuts (2.2) to the forward most tube on the footrest support as shown in **Figure 2**. **Note:** Do not tighten at this time.
2. Using the plow mount (1) as a template, drill a hole through the plastic skid plate using a 11/32" drill bit in each of the four holes on the front of the mount as shown in **Figure 3**.
3. To gain access to the frame tube, remove the plastic guard for the coolant hoses by removing the two hex bolts as shown in **Figure 4**. Secure the front of the plow mount (1) using the remaining U-Bolts (2.1) and Nuts (2.2) placing them over the frame tube and through the holes drilled in step 2 as shown in **Figure 5**.
4. Replace the plastic guard removed in step 3 and tighten all hardware evenly.

