

CAN-AM MAVERICK

Rear Receiver PART # 101125
 Hardware Kit: HK-309, HK-031

Kit Components:


Qty.	Part Description
1.....	Receiver Plate
6.....	3/8"-16 x 3.5" Hex Flange Bolt
6.....	3/8" Flanged Nylock Nut
1.....	UTV Mini Rocker Kit (HK-031)

INSTALLATION INSTRUCTIONS:


1. Use a jack (A) to raise up the rear end; taking pressure off of the rear a-arms.

Note: You may need to raise or lower this while removing or installing the new bolts. There is NO specific height that works best.


2. Remove all 6 a-arm bolts (B) as shown in Figure 3.
3. Place mount up to frame and install using 3.5" bolts and nuts provided in the hardware kit. See Figure 4. **Note: Torque bolts to 48 ft-lbs.**
4. If installing a winch see Figure 5. Use hardware provided with your winch. See winch manual for wiring, Page 2 for tips.




"Figure 1"




"Figure 2" Raising the Rear End



"Figure 4" Mount Install



"Figure 3" Bolt Removal



"Figure 5" Winch Install


WIRING INFORMATION

1. For contactor location please see “Figure 6”.

Note: This is located behind the radiator on the passenger side of the machine. This is just a suggestion that will work with the wiring provided with the winch.

The wires will need to be switched for this machine. The longer wires (Blue/Yellow) will be used to go from the battery to the contactor. The shorter wires (Black/Red) will be used to go from the winch to the contactor.


2. Mini-Rocker Switch Hardware kit. This allows you to mount your usual handle bar mounted switch to almost any desired location.
 - a. Remove handlebar mount hardware from the switch.
 - b. Locate desired mounting location
 - c. Mark and drill two switch holes through dash using switch housing as a template
 - d. Drill a 3rd hole for the switch wiring.
 - e. Assemble per Figure 8.
3. Find a location that suits your purposes for the mini-rocker switch and hand remote.
4. Wire the red ignition wires from the controllers to a key controlled wire. Usually a good spot for this is the red wire on the accessory plug.



“Figure 6” Contactor Location



“Figure 7” Battery Location
(Battery is located under panel in the bed.)



Optional Switch Mount Instructions*

“Figure 8” Mini-Rocker Mounting