

Honda Foreman / Rubicon Winch Mount

Winch Mount


Kit Components:

PART # 100585

HK-020

<u>Qty</u>	<u>Part Description</u>
1.....	Winch Mount
2.....	U-Bolt Plate (B2)
2.....	1/4"-20 x 1" x 1-1/2" SQ-Bolt (B1)
4.....	1/4" Nylock Nuts (B3)
2.....	M8-1.25 x 30mm HH Bolt (B4)
6.....	5/16" SAE Flat Washers

***NOTE:** The winch mount plate will have multiple holes for different locations of the winch. Use the best locations for your winch.*



When installing your winch the motor leads must be parallel with the ground. If they are not rotate leads as shown in attached instructions

INSTALLATION INSTRUCTIONS:

NOTE: DISASSEMBLY OF THE FRONT OF YOUR ATV IS ONLY REQUIRED ON THE RUBICON MODEL. FOR ALL OTHER FOREMAN MODELS PLEASE START AT INSTRUCTION #6.

1. Begin by removing the front skid plate located on the front of your ATV. Remove the (4) side 8mm bolts and the (4) 6mm bolts securing the front skid plate, "Figure 1"




Figure 1 Remove Front Skid Plate



Figure 2 Remove the Four Plastic Rivets

2. Remove the (4) plastic rivets on each side of the front plastic fascia, "Figure 2". Use a large screwdriver to carefully remove the center rivet. After removing the center rivet, remove the rivet housing.




Figure 3 Front Bumper Bolts

3. Remove the (2) 6mm bolts that attach the front bumper to the plastic headlight assembly, "Figure 3"

4. Remove the (2) top 8mm bumper bolts that attach the front bumper to the front rack, "Figure 4"



Figure 4 Remove Top Bumper Bolts

5. Remove the (2) bottom bumper bolts that attach the bumper to the bottom of the ATV frame, "Figure 5"



Figure 5 Remove Bottom Bumper Bolts

6. Remove the (2) middle bumper bolts that attach the bumper to the middle of the ATV frame, "Figure 6". These two bolts will be replaced with the (2) supplied M8 bolts.




Figure 6 Remove Middle Bumper Bolts

7. Place the mounting plate into position on the front bumper. Install (2) U-bolts (B1), (2) U-bolt plates (B2), and (4) lock nuts (B3) that are supplied with this kit, "Figure 7". ***See Exploded View on page 1 for bolt plate attachment. Do not tighten U-bolts at this time.***
8. Attach fairlead to the fairlead mounting location using hardware supplied with your winch or fairlead. (*not included with this kit*) Torque fairlead bolts to approx. 25 ft-lb.
9. Mount your winch to the mounting bracket using the hardware supplied with your winch, "Figure 7"




Figure 7 Place Mounting Plate, Fairlead, and Winch onto front Bumper

10. If your ATV is a Rubicon you can now place the front bumper with attached winch assembly back onto the ATV frame. Reinstall the (4) bolts that were removed in steps 4 & 5. ***Do not tighten at this time.***
11. Install the supplied 8mm bolts (B4), "Figure 8", into the middle bumper mounting location, Step 6. ***Do not tighten at this time.***




Figure 8 Install New Supplied 8mm Bolts

12.If your ATV is a Rubicon you can now reinstall the (2) 6mm bolts that were removed in step 3, the (4) rivet fasteners that were removed in step 2, the front plastic skid plate that was removed in step 1, and the (4) side 8mm bolts and (4) bottom 6mm bolts. Do not tighten at this time. “Figure 9”

13.Now you can tighten all nuts and bolts to the recommended torque of: “Figure 9”

- 6mm bolts -12 N-m (9 ft-lb)
- 8mm bolts -37 N-m (27 ft-lb)
- ¼” U-bolts-10 N-m (7 ft-lb)

14.Using the instructions provided with your Winch, wire accordingly.

RECOMMENDED CONTACTOR LOCATION

1. Contactor Location

- The contactor location is located in the right rear inner fender, on the right side of the rear tool box, “Figures 12 & 13”
- Remove the wire harness, “Figure 10”, from the bracket that holds the wire harness in position.
- Using a drill and a ¼” drill bit, remove the top of the rivet head to remove the wire harness bracket.
- Relocate the wire harness that was removed along the rear rack tube, “Figure 12”. Use a zip-tie to secure the wire harness.
- Position the contactor with the posts for the positive battery cable in the lower left corner, “Figure 13”. Mark and drill ¼” holes for the contactor. Secure the contactor with hardware supplied with your winch. Tighten the nuts to a recommended torque of 7 N-m (5 ft-lb).




Figure 10 Remove Wire Harness from Bracket




Figure 9 Completed Winch Installation



Figure 11 Remove Wire Harness Bracket




Figure 12 Contactor Location - Right side of tool box




Figure 13 Contactor Location - Right side of tool box